







Parça Listesi

Spare parts list

	32 985 1 x		37 527 2 x		208 236 4 x		208 447 2 x
	34 995 2 x		122 950 1 x		208 238 3 x		208 449 3 x
	35 061 2 x		130 593 2 x		208 240 13 x		208 473 2 x
	35 063 2 x		172 541 3 x		208 241 12 x		208 474 2 x
	35 065 1 x		185 695 1 x		208 242 10 x		208 476 3 x
	35 072 1 x		203 324 1 x		208 244 2 x		208 479 4 x
	35 073 5 x		203 654 1 x		208 245 4 x		208 480 3 x
	35 087 2 x		208 227 4 x		208 312 6 x		208 481 6 x
	35 088 2 x		208 228 3 x		208 316 1 x		208 482 1 x
	35 129 1 x		208 229 4 x		208 428 2 x		208 484 3 x
	35 945 2 x		208 230 4 x		208 432 3 x		208 950 11 x
	35 977 1 x		208 231 2 x		208 438 1 x		210 308 2 x
	36 573 1 x		208 233 36 x		208 443 1 x		
	36 819 2 x		208 234 10 x		208 445 6 x		
	36 911 2 x		208 235 2 x		208 446 6 x		

- Tüm parçalar, özellikle hareketli parçalar, gerektiği gibi bakımı yapılmalı ve temizlenmelidir.
- All components, especially moving parts, should be maintained and cleaned as necessary.